

# Cover Fitting Instructions

The fire control panel cover is located on the back box using two locating lugs on each side face and held in place with four screws. The cover needs to be earthed to the back box and a lead is provided for this purpose.

Your kit PN: 020-639 should contain:

Cover  
M3 x 6 button-head hex, steel screws (4 off)  
Allen key 2mm

PN: 004-102-XXX  
PN: 775-059  
PN: 334-051

## Check Your Equipment....

Before installing the cover, remove all packaging and inspect for any damage that may have occurred during transit. If no damage is evident, proceed using the instructions below. In the unlikely event that damage has occurred, DO NOT PROCEED, contact your supplier and refer to the **Installation, Commissioning & Configuration Manual** for guidance on what to do next.

## Procedure

- 1 With the cover (A) correctly orientated, offer it to the panel back box (B).
- 2 With the cover adjacent to the back box, connect the flying earth lead (C) to the blade connector (D) on the inside face of the cover using the shrouded earth blade connector (E).

**Note:** All blade connections to earth incorporate a locking barb. To make a connection, push the shrouded receptacle (1) on to the earth blade (2). To remove this connection, pull the shroud (1), NOT the earth wire.

- 3 Ensure that the four locating lugs (F) correctly engage the side walls of the back box. Only when this is done should you push the cover fully home.

**Note:** The lugs ensure that the holes of the cover will line up with the corresponding threaded holes in the back box.

- 4 Secure the cover in position using the four security screws provided. Tighten the screws using the provided 2mm Allen key.

