B3123P30 Release Notes

Zhejiang Uniview Technologies Co., Ltd.

B3123P30 Release Notes

Keywords: Version information, usage notes, precautions.

Abstract: This document provides information about the **B3123P30** board software, including version information, usage notes, precautions, and features.

Acronym

Acronym	Full Name
NVR	Network Video Recorder

2018-6-5 Page 1

Contents

1 Version Information	3
1.1 Version Number ·····	3
1.2 Applied Product Models ·····	3
1.3 Release History ·····	3
2 Usage Notes ·····	4
3 Software Features ·····	4
4 Version Change Description · · · · · · · · · · · · · · · · · · ·	4
4.1 Feature Change Description ·····	4
4.2 Operation Change Description	10
5 Related Documents and Delivery Method	11
6 Version Upgrade Guidance ·····	11
6.1 Precautions	11
6.2 Upgrade Procedure ·····	11
6.3 Upgrade Through the System Interface ······	11
6.4 Upgrade Through the Web Interface·····	12

1 Version Information

1.1 Version Number

B3123P30

1.2 Applied Product Models

Table 1 Applied Product Models

Product Models	Description
NVR304-16E	4 slots, 16-ch, H.264 and H.265, 4K ultra HD.
NVR304-32E	4 slots, 32-ch, H.264 and H.265, 4K ultra HD.
NVR302-08E-P8	2 slots, 8-ch, 8 PoE interfaces, H.264, H.265, 4K ultra HD.
NVR302-16E-P8	2 slots, 16-ch, 8 PoE interfaces, H.264, H.265, 4K ultra HD.
NVR302-16E-P16	2 slots, 16-ch, 16 PoE interfaces, H.264, H.265, 4K ultra HD.
NVR304-16EP	4 slots, 16-ch, 16 PoE interfaces, H.264, H.265, 4K ultra HD.
NVR304-32EP	4 slots, 32-ch, 16 PoE interfaces, H.264, H.265, 4K ultra HD.

1.3 Release History

Table 2 Released Versions

Version No.	Basic Version No.	Released On
B3123P30	B3123P23	2018-05-31
B3123P23	B3123P20	2018-04-21
B3123P20	B3122P31	2018-03-14
B3122P31	B3122P25	2017-11-29
B3122P25	B3122P16	2017-10-24
B3122P16	B3122P10	2017-09-26
B3122P10	B3121P15	2017-08-21
B3121P30	B3121P15	2017-10-25
B3121P15	B3121P10	2017-05-24
B3121P10	B3120P11	2017-04-27
B3120P11	B3119P22	2017-02-20
B3119P32	B3119P22	2017-04-06
B3119P22	B3118P31	2017-01-19
B3118P31	B3118P29	2016-09-26
B3118P29	B3118P27	2016-09-10

B3118P27	B3118P26	2016-08-30
B3118P26	B3118P15	2016-08-22
B3118P15	B3117P25	2016-07-23
B3117P25	B3116P23	2016-05-25
B3116P23	B3116P20	2016-02-02
B3116P20	B3115P35	2016-01-18
B3115P35	B3115P30	2015-11-05
B3115P30	Initial release	2015-10-14

2 Usage Notes

None.

3 Software Features

Table 3 Software Features

Service	Feature
Audio and video decoding	H.264 and H.265, 4K resolution display, up to 16Mbps bit rate.
Data storage	Local storage of recordings in hard disk(s).
Web-based management	Web-based user interface for device configuration and management.

4 Version Change Description

4.1 Feature Change Description

Table 4 B3123P20 Feature Changes

Item	Feature	Description
	Add IPC across Internet	Add IPCs to the NVR across the Internet.
New features	SNMP	System time obtainable.
	POS connection	Connect to POS and display POS OSD.
	Improved diagnostic info collection	Support the backup of IPC logs on NVR.
	Alert configuration	Added two alert types: array degrade and array damaged.
Improved	Alarm window	Displays alarm status with two tabs and added multiple alarm types.
features	Web recording download	Include recording start and end times in filenames for easier differentiation.
	Maintenance info collection	Added network bandwidth statistics on the Web.
Deleted	None	None

Item	Feature	Description
features		

Table 5 B3122P10 Feature Changes

Item	Feature	Description
New features	USB connected burner	Connect to an external USB burner to burn recordings to a disc. Supported by some models only.
	TLS/SSL	Achieves complete SSL/TLS encryption.
	Maintenance info storage	Save space by saving maintenance logs to hard disks.
	IPC upgrade by cloud	Adds a Check button (to check for update) and displays latest version info.
Improved	3G/4G	Adds custom mode for access points.
features	Playback	Allows user to choose third steam for playback.
	Alarm triggered preview	Supports multi-window display for alarm-triggered preview.
	N+1 function	Supports IPC connected by RTSP.
	Parameter configuration	Increases image quality levels from 6 to 9.
	Password policy	Added an enable/disable setting and changed some policy.
Deleted features	None	None

Table 6 B3121P10 Feature Changes

Item	Feature	Description
	Intelligent Mark	Displays areas/lines drawn for face detection, intrusion detection, and cross line detection, as well as changed smart data, on the live view, behavior search and alarm configuration windows.
	Defocus Detection	Determines whether the camera is defocused, and if so triggers alarm.
	Scene Change	Determines whether the scene is changed, and if so triggers alarm.
New features	Auto Tracking	Supports auto tracking of moving objects with IP cameras supporting this function.
reatures	People Counting of Multiple Cameras	Displays people counting data of multiple cameras together.
	People Counting OSD	Displays people counting data by OSD in real time.
	Sort Camera	Supports changing sequence of selected cameras in camera list.
	Watermark	Supports custom encryption of video data with compatible IP cameras and EZPlayer, to avoid video info deletion and modification.
	Optimized H.265 compatibility	Supports third-party H.265 IP camera connecting to Uniview NVR through ONVIF.
	Log Export Format	The default format of exported logs is changed from TXT to CSV.
Improved features	Auto-Delete File(s)	Adds auto-delete file(s) configuration on Web client.
reatures	Admin Management	Supports admin to force guest offline.
	Diagnostic Information	Adds basic information of IP camera to exported diagnostic information.
	Network Setting	Supports auto-completion of subnet mask when setting network

Item	Feature	Description
		address.
	Quick Match for Camera List	Supports input selection and fuzzy matching for camera list.
	Dongle	Fits for more models of 3G/4G dongle.
	Professional Surveillance Keyboard	Supports selecting camera and date for playback. Supports patrol and route.
Deleted features	None	None

Table 7 B3120P11 Feature Changes

Item	Feature	Description
New features	Certain fisheye camera models	Supports dewarping of certain fisheye camera models on NVR Web client for live view and normal playback images.
	Optimized maintenance	The size of Ping packet and captured packet is configurable.
lmp royed	Optimized camera configuration	Supports coping IP camera configurations of OSD, motion detection, video loss and tampering detection.
Improved features	Optimized PTZ preset	Allows the user to delete preset and only added preset will be displayed in the list.
	Optimized password recovery	Supports scanning QR code on mobile client to recover password.
Deleted features	None	None

Table 8 B3119P22 Feature Changes

Item	Feature	Description	
New	U-Code	U-Code is a patented technology of Uniview that accomplishes higher compression efficiency than H.264/H.265.	
	NAS	Supports NAS storage device.	
	Auto guard	Enables the PTZ camera to operate automatically as configured if no operation is performed during a certain time period. This function can avoid situations where the camera is left to monitor an incorrect scene by user's negligence.	
features	Multicast	Makes live view possible even when the number of connecting Web clients exceeds the limit the NVR can accommodate.	
	PoE/network port status	Displays port status for network ports, and port status and power information for PoE ports.	
	USB Device window	Automatically displays the window when a USB storage device is plugged in during device startup or in preview status. The window can also be opened by clicking the USB icon on the screen toolbar.	
Improved features	Uniview logo	Displays Uniview logo in idle preview windows. This feature is only available to Uniview version.	
	Auto switch to	Automatically switches to H.265 and U-Code when connected by Uniview IPC and sends default bitrate settings to IPC.	
	Copy video compression and U-Code settings	Allows user to copy video compression and U-Code settings and quickly apply them to other IPCs.	
	Draw schedules	Allows users to make recording and snapshot schedules by drawing.	

Item	Feature	Description	
	Instant playback	ayback Instant playback time is now configurable.	
	Mouse operation	e operation Allows user to adjust the moving speed of mouse pointer.	
	IPC upgrade Upgrade a batch of IPCs by cloud or USB storage device.		
	Preview	Live view window's yellow boarders disappear automatically in 20 seconds if no operation is performed. The window borders flash white when taking a snapshot during live view or playback. Restore default resolution by pressing and holding the scroll wheel for at least 3 seconds.	
	Snapshot		
	Resolution		
	DHCP	DHCP is enabled by default for international versions.	
	Playback by tag	Allows playback by tag on Web client.	
Deleted features	None	None	

Table 9 B3118P15 Feature Changes

Item	Feature	Description		
	N+1 hot spare	Data and service backup between devices; supports data transfer back to the working device from hot spare when the working device is restored to normal status.		
	VCA	Work with smart IPC to achieve VCA functions (smart detection and smart search), enhanced playback by event.		
	Fisheye	Supports connection to certain models of Uniview fisheye cameras.		
Newly	RTSP-based connection to IPC	Adds IPC by RTSP for live view and playback (IPC configuration not supported).		
added features	RTSP URL format on screen	Displays RTSP URL format and a description, and users can view live video from a channel of the NVR by visiting the corresponding URL using an RTSP-enabled device.		
	Ucode	Uniview's private encoding rules which greatly improve the compression rate compared with average encoding modes.		
	IPv6	Supports IPv6 and offers three options to set an IPv6 address: Manual, DHCP, Router Advertisement.		
	3G/4G	Enables connection to the Internet through cellular network (WCDMA, CDMA2000, TD-SCDMA, 4G LTE) using a dongle.		
	Quick view of serial number	View the device's serial number by double-clicking the lower left corner of the login dialog box as admin.		
	Improved encoding configuration	Automatically refreshes encoding configurations; automatically changes bit rate as the user changes resolution and frame rate.		
l man may card	One-click cancellation of binding to EZCloud	Allows the user to cancel binding to EZCloud account by clicking the Delete button without visiting the EZCloud website.		
Improved features	Enhanced ease of use	Displays device operation time, camera offline cause, a system message when the USB storage device is unplugged, and added the Camera Name column under Advanced.		
	Enhanced corridor mode	Added 4/9/10/12/16 corridor modes on the system interface.		
	Added OSD configurations	Added font color and size options for OSD configuration.		

	Optimized playback	Supports reverse playback; max. 256x playback speed on the system interface, and 16x playback speed on the web interface; with apparently improved fluency at low playback speed.
	Optimized alarm- triggered preview	Changes alarm-triggered preview from "sequence display three times" to "display from alarm is reported till alarm is cleared.
Deleted features	None	None

Table 10 B3117P25 Feature Changes

Item	Feature	Description		
	Independent video output	Independent play and playback of different live videos; dual-preview images.		
	Cache post recording	Videos are saved to the SD card if connection to the IP camera is lost. When the camera gets back online, videos saved on the SD card will be transmitted and stored on the NVR. No configuration is required.		
	Disk group management	Allows the user to designate disks to different groups and specify different disk groups to store video from different cameras, making storage space calculation for each camera unnecessary.		
Newly	Redundant storage	Extra copy for important recordings.		
added features	Improved colors for the user interface	Uses Uniview standardized style to improve the user interface and enhance the identification of icons and symbols.		
	Web-based control of system interface	Allows the user to change image resolution and preview sequence on the system interface through the Web interface.		
	Alarm-triggered pop-up window	A window pops up on the system interface to alert the user when an alarm occurs.		
	ARP protection	Obtains the MAC of its gateway at first startup and communicates with the gateway with this MAC ever since. The MAC can be edited as needed.		
	Optimized system interface for ease of use	Improves window toolbar, shortcut menu, PTZ control, startup wizard, and the menu bar at the bottom of the screen for easier use.		
	Enhanced playback on the Web interface	Allows smart playback and event-based playback on the Web interface.		
	PTZ control	The system interface supports PTZ control using shortcut keys.		
	Enhanced ability to connect to IP cameras	Added the following for Uniview IP cameras: 1. White balance mode 2. Scenes		
Improved		3. Alarm indicating failed camera access attempts		
features	Enhanced downlink ONVIF	Allows the user to disable time synchronization with IP cameras. This feature prevents the problem that some third-party IP cameras cannot get online because they do not support time zone synchronization or time synchronization.		
	Enhanced uplink ONVIF	Combines uplink ONVIF port with HTTP port to improve networking adaptability.		
		2. Reports more alarm types (disk offline, disk abnormal).		
		3. Allows the obtainment and modification of the device name.		
	Log export	Allows the user to export logs as CVS files for easy search and management.		
	One plug-in for NVR	Allows the user to install the plug-in only once for accessing the NVR		

Item	Feature	Description	
	and IPC	and IP cameras using a Web browser. Changes the default IP address to 192.168.1.30 while also supports 192.168.0.30 to adapt to default network environments of most routers and network switches and simplify configuration.	
	Plug&play		
	Network security	Improves protection against network attacks for better user privacy.	
	User management	Increases the number of concurrent remote users from 16 to 128.	
	Web-based upgrade	Filters file types for local upgrade through the Web interface. Allows the changing of user password through EZTools.	
	Maintenance tool		
Deleted features	None	None	

Table 11 B3116P20 Feature Changes

Item	Feature	Description	
	Manual alarm output control	Enables the user to trigger or clear output alarms manually.	
	Preview control	Displays a logo in preview windows for the user with no live view permission in these windows.	
	Packet capture on Web	Enables the user to capture packets on the NVR's NIC from the Web.	
	Drag in preview window	Enables the user to switch a camera by dragging the preview window.	
	Watermark on recording to prevent tampering	Enables the user to use a tool and determine whether the exported video recorded from a watermark-enabled camera has been tampered with.	
Newly added	Playback by log	Enables the user to play recordings based on log search results in the log query window.	
features	Preview in camera window on NVR	Enables preview in the camera window.	
	Bad sector detection	Enables disk status self-test and back sector detection.	
	UNP connection by dial-up	Enables connection to a UNP server by dial-up.	
	Audio detection alarm	Can identify and raise audio detection alarms when connected to IP cameras that support audio detection.	
	Duzzer configuration	Allows users to stop buzzer manually.	
	Buzzer configuration	2. Enables the buzzer to stop sounding when the alarm is cleared.	
	Optimized startup wizard	Displays different procedures intelligently, simplifies steps and improves usability.	
	Optimized stream selection in multi-window preview in system interface	Optimizes rules for choosing streams in multi-window preview: uses sub stream by default and uses main stream if sub stream is unavailable; enables stream preference configuration (main or sub stream) in multi-window preview.	
Improved features	Enhanced capability of connecting IP cameras via ONVIF	Enables compatibility with XiongMai IP cameras, enables automatic adding of IP cameras and changing of IP addresses.	
	Enhanced private protocol	Enables the user to upgrade IP cameras by cloud and restore factory default settings for IP cameras on the NVR.	
	Audio output control	The audio on/off button, switch camera button, and the volume slider are moved to the preview window toolbar, allowing the user to	

Item	Feature	Description	
		mute or play sound for each channel separately.	
		2. Enables the configuration of audio data transfer to control whether the IP camera sends audio data or not.	
	Image snapshot and upload via FTP	Supports scheduled snapshot, alarm-triggered snapshot, and snapshot sending via e-mail and upload via FTP. Models that support this function: NVR308-32R, NVR308-64R.	
	Snapshot as email attachment	Enables snapshot sending by email. Models that support this function: NVR308-32R, NVR308-64R.	
	Optimized playback	Starts playback automatically for the corresponding camera when the user selects a preview window and then selects Playback from the shortcut menu.	
	operation	2. Enables the user to deselect all the selected cameras by clicking the Close All button added in the playback window.	
	Optimized zoom area	Specifies aspect ratio for zoom areas drawn by the user.	
	Adaptive to changed camera IP address	The NVR can automatically identify and reconnect DHCP-enabled IP cameras after their IP addresses are changed.	
	Enhanced uplink ONVIF capability	When connected to a higher-level management platform via ONVIF, the NVR supports recording type search, disk status search, smart playback, and enables snapshot from the platform without establishing live view.	
	Maintenance info	Exported diagnosis information is improved.	
	collection	2. Enables the user to switch on the debug function with Ctools to gather more information.	
	Enhanced client Enables the user to test network bandwidth and dia functions EZStation and mobile client.	Enables the user to test network bandwidth and diagnose network delay on EZStation and mobile client.	
	Automatic patrol resumption for PTZ camera	due to power failure. To a light the PTZ camera to resume interrupted patrol after a residue to power failure.	
	Domain name identification for NTP and other servers		
	Enhanced keyboard functions	Enables Uniview surveillance keyboards to control presets of PTZ cameras.	
	Optimized cloud status	Displays causes for devices failed to connect to EZCloud.	
Deleted features	None	None	

4.2 Operation Change Description

None

5 Related Documents and Delivery Method

Table 12 Related Document List

Manual Name	Manual Version	Delivery
Network Video Recorders Quick Guide	V1.00	Deliver with device.

6 Version Upgrade Guidance

6.1 Precautions

- This software system includes a software program mirror (Program.bin). Before you start
 upgrade, please back up configuration data through the system or Web interface in case
 the upgrade fails.
- Maintain proper network connection and power supply during the upgrade.

6.2 Upgrade Procedure

The version can be upgraded through the system interface and the Web interface, both support cloud upgrade.

6.3 Upgrade Through the System Interface


The system interface provides two options for upgrading the system software: local upgrade using a USB drive and cloud upgrade.

1. Local upgrade

Before you start, copy the correct upgrade file to the root directory of the USB drive.

- (1) Plug the USB drive into the USB interface on the NVR.
- (2) Log in to the system interface as "admin".
- (3) Click Maintain > Upgrade.
- (4) Click Upgrade, select the upgrade file from the drop-down list, and then click Upgrade. A prompt message appears.
- (5) Click OK.

Figure 1 Prompt Message



(6) The NVR will restart automatically when the upgrade is completed.

2. Cloud upgrade

Before you start, check that the NVR is correctly connected to the public network.


- (1) Click **Maintain > Upgrade**, and then click **Check** to check for the latest version.
- (2) Click **Upgrade** after a newer version is detected.

6.4 Upgrade Through the Web Interface

Perform the following steps to upgrade through the Web interface:

- (1) Log in to the Web interface as "admin".
- (2) Click Settings > Maintenance > Maintenance.

Figure 2 System Maintenance



- (3) Click **Browse** right to the **Upgrade** field, select the **Program.bin** file to upgrade, and then click **Upgrade**.
- (4) If the NVR is connected to the public network, you may also click **Check** to perform a cloud upgrade. If a newer version is detected, a prompt message will appear. Click **OK** to start upgrade.

Figure 3 Prompt Message



(5) The NVR will restart automatically when the upgrade is completed.

© 2018 Zhejiang Uniview Technologies Co., Ltd. All Rights Reserved.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Zhejiang Uniview Technologies Co., Ltd.

The information in this manual is subject to change without notice.