IPC_8101_IN_Eng-F150801

Release Notes

Zhejiang Uniview Technologies Co., Ltd

IPC_8101_IN_Eng-F150801 Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for IPC_8101_IN_Eng-F150801

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

1 Version Information

1.1 Version Number

IPC_8101_IN_Eng-F150801

1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_8101_IN_Eng-F150801	IPC_8101_IN_Eng-F50601P03	2015-09-15	improved release

1.3 Version Mapping Table

Table 2 Version mapping table

Product Mapping Item	Version No. (For External)
NVR202-08EP	B2315P05
NVR201-04E	B2315P05
NVR201-04LP	B2315P05
NVR201-08L	B2315P05

Table 3 Product models and corresponding versions

Product Series	IPC Series	Initial Version
Series	IPC221L, IPC221E, IPC222E, IPC221S, IPC321E, IPC321L, IPC321S, IPC322E	
Models	**IPC221L series:** IPC221L-IR-F60-IN, IPC221L-IR-F120-IN	**F8111IN141101**
	IPC221E series: IPC221E-DIR-F120-IN, IPC221E-DIR-F60-IN	
	IPC222E series: IPC222E-IR-F60-IN, IPC222E-IR-F120-IN	
	IPC221S series: IPC221S-IR-F60-IN, IPC221S-IR-F120-IN	
	IPC321E series: IPC321E-DIR-F36-IN, IPC321E-DIR-F60-IN, IPC321E-D-F21-IN	
	IPC321L series: IPC321L-IR-F36-IN, IPC321L-IR-F60-IN	
	IPC321S series: IPC321S-IR-F36-IN, IPC321S-IR-F60-IN	
	IPC322E series: IPC322E-IR-F36-IN, IPC322E-IR-F60-IN	
Target file name	IPC_8101_IN_Eng-F150801.zip	

2 Feature Change Description

New features:

1.Password MD5 encryption based on customer-supplied strings;ONVIF time sync.

2.Half hour time zone and snapshot function.

3.Password retrieval.

4.Setting IP camera name and location in ONVIF.

5.Optimized motion detection.

6. New standard for ONVIF alarm format.

Solved issues:

1.Failed to add motion detection areas.

3 Usage Notes

None.

4 Version Upgrade Procedure

4.1 Upgrade Overview

4.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture


As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

4.2 Upgrade Procedure

4.2.1 Upgrade Through the Web

(1)   Log in to the Web interface as **admin** (default password: admin).

(2)   Click **Setup** > **Maintenance** > **Device Maintenance**. The **Device Maintenance** page is displayed.

(3)   Click **Browse** in the **Software Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_8101_IN_Eng-XXXXX.zip, and then click **Open**.

(4)   Click **Upgrade**. You cannot operate on other pages during the upgrade process.

(5)   Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.