IPC_G6102-B150801 Release Notes

Zhejiang Uniview Technologies Co., Ltd

IPC_G6102-B150801 Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for

IPC_G6102-B150801.

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

1 Version Information	3
1.1 Version Number ·····	3
1.2 Release History ·····	3
1.3 Version Mapping Table·····	3
2 Version Upgrade Procedure ·····	3
2.1 Upgrade Overview·····	3
2.1.1 Version Upgrade Environment·····	4
2.2 Upgrade Procedure ·····	4
2.2.1 Upgrade Through the Web ······	4

1 Version Information

1.1 Version Number

IPC_G6102-B150801

1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	eased On Remarks	
IPC_G6102-B150801	IPC_G6102_IN_Eng-B150701P0 5	2015-09-22	improved release	

1.3 Version Mapping Table

Table 2 Version mapping table

产品配套项目	版本号(对外)	说明
NVR202-08EP	B2315P05	无
NVR201-04E	B2315P05	无
NVR201-04LP	B2315P05	无
NVR201-08L	B2315P05	无
NVR202-08E	B2315P05	无
NVR201-04EP	B2315P05	无

Table 3 Product models and corresponding versions

Product Series	IPC Series	Initial Version
Series	IPC2124SR3	
Туре	IPC2124SR3 Series: IPC2124SR3-DPF36、 IPC2124SR3-DPF60 、IPC2124SR3-DPF120	B150701P 05
Target file name	IPC_G6102-B150801.zip	


2 Version Upgrade Procedure

2.1 Upgrade Overview

2.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture




As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

2.2 Upgrade Procedure

2.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: admin).
- (2) Click Setup > Maintenance > Device Maintenance. The Device Maintenance page is displayed.



- (3) Click Browse in the Software Upgrade area. In the Select dialog box that appears, select the upgrade file package, for example, IPC_G6102_IN_Eng-XXXXX.zip, and then click Open.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.

(5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

 $\hbox{@ 2014-2015},$ Zhejiang Uniview Technologies Co., Ltd. All Rights Reserved.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Zhejiang Uniview Technologies Co., Ltd.

The information in this manual is subject to change without notice.