IPC_HCMN1102-R5028P05D1603

Release Notes

Zhejiang Uniview Technologies Co., Ltd

IPC_HCMN1102-R5028P05D1603

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for IPC_HCMN1102-R5028P05D1603.

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

1 Version Information

1.1 Version Number

IPC_HCMN1102-R5028P05D1603

1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_HCMN1102-R5028P05D1603	IPC_HCMN1102-F5027P01D1511	2016-5-24	Improved relese

1.3 Version Mapping Table

Table 2 Version mapping table

Product Mapping Item	Version No. (For External)
NVR301-04-P4	B3202
NVR301-08-P8	B3202

Table 3 Product models table

Product Series	IPC Series
Series	IPC6221ER, IPC6221LR,IPC6222ER,IPC641E, IPC6241SR, IPC6242SL, IPC6242SR, IPC641E, IPC642E
Models	**IPC6221ER series:** IPC6221ER-X20,IPC6221ER-X20P, IPC6221ER-X30, IPC6221ER-X30P
	IPC6221LR series: IPC6221LR-X20S, IPC6221LR-X20SP
	IPC6222ER series: IPC6222ER-X20, IPC6222ER-X20P, IPC6222ER-X30, IPC6222ER-X30P
	IPC6241SR series: IPC6241SR-X22,IPC6241SR-X30, IPC6241SR-X20
	IPC6242SL series: IPC6242SL-X22,IPC6242SL-X33, IPC6242SL-X22G、 IPC6242SL-X33G
	IPC6242SR series: IPC6242SR-X22,IPC6242SR-X30, IPC6242SR-X33、 IPC6242SR-X20
	IPC641E series: IPC641E-X22I-IN, IPC641E-X22-IN, IPC641E-X22IR-IN
	IPC642E series: IPC642E-X22I-IN, IPC642E-X22-IN, IPC642E-X22IR-IN
Target file name	IPC_HCMN1102-R5028P05D1603.zip

2 Feature Change Description

2.1 New features

1.Login with IPv6 address.

2.Custom time to resume interrupted scheduled patrol.

3.Custom time to resume home position.

4.Internet access with weak password will be denied.

5.Fast forward/backward and timeline bar-dragging when playing queried recordings in Internet Explorer.

3 Version Upgrade Procedure

3.1 Upgrade Overview

3.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture

As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

3.1.2 Version Upgrade Modes

You can upgrade through the Web.

3.2 Upgrade Procedure

3.2.1 Upgrade Through the Web

(1)   Log in to the Web interface as **admin** (default password:123456).

(2)   Click **Setup** > **Maintenance** > **Device Maintenance**. The **Device Maintenance** page is displayed.

(3)   Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_HCMN1102 -XXXXX.zip, and then click **Open.**

(4)   Click **Upgrade**. You cannot operate on other pages during the upgrade process.

(5)   Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.