# IPC\_HCMN2103-B0016P12D1611

# **Release Notes**

Zhejiang Uniview Technologies Co., Ltd

# IPC\_HCMN2103-B0016P12D1611 Release Notes

#### Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for IPC\_HCMN2103-B0016P12D1611.

#### Acronym:

Acronym	Full Name	
IPC	IP Camra	

# Content

1 Version Information3
1.1 Version Number ······3
1.2 Release History ······3
1.3 Version Mapping Table ······3
2 Feature Change Description4
3 Version Upgrade Description4
4 Version Upgrade Procedure4
4.1 Upgrade Overview4
4.1.1 Version Upgrade Environment ······4
4.1.2 Version Upgrade Modes5
4.2 Upgrade Procedure ······5
4.2.1 Upgrade Through the Web ······5

## 1 Version Information

### 1.1 Version Number

IPC\_HCMN2103-B0016P12D1611

### 1.2 Release History

#### Table 1 Released versions

Version No.	No. Basic Version No.		Remarks
IPC_HCMN2103-B0016P12D1611	IPC_HCMN2103-B0015P30D1607	2017-2-7	Improved relese

### 1.3 Version Mapping Table

Table 2 Version mapping table

Product Mapping Item	Version No. (For External)	
NVR201-04LP	4LP R2318P01	
NVR202-08EP	R2318P01	

#### Table 3 Product models and corresponding versions

Product Series	IPC Series		
Series	IPC6252SR,IPC6253SR, IPC252ERA, IPC6252SFW, IPC6222ER, IPC6252SL, IPC6852SR		
	IPC6252SR Series: IPC6252SR-X22U、IPC6252SR-X22UG、IPC6252SR-X33U		
	IPC6253SR Series: IPC6253SR-X33		
	IPC6252SFW Series: IPC6252SFW-X22U		
Models	IPC252ERA Series: IPC252ERA-X22DUG		
	IPC6222ER Series: IPC6222ER-X20P-B 、IPC6222ER-X20-B 、IPC6222ER-X30P-B		
	IPC6222ER-X30-B		
	IPC6252SL series: IPC6252SL-X33UP		
	IPC6852SR series: IPC6852SR-X44U		
Target file name	IPC_HCMN2103-B0016P12D1611.zip		

### 2 Feature Change Description

Item	Feature	Description	
Newly added features	SD	SD' s capacity allocation will keep the original configuration when IPC is to restore the default.	
	Plug-in	Update the plug-in of IP camera.	
	Delays of alarm output	The minimum delays of alarm output from 5s to 1s.	
	OSD	<ol> <li>Scroll OSD.</li> <li>Picture overlay OSD.</li> </ol>	
Improved	DIS	Improved the DIS for PTZ Dome.	
features	Images	Improved images.	
Deleted features	None	None	


### 3 Version Upgrade Description

- 1. Version B5010D1510 supports normal upgrade.B5010D1510 and later versions cannot be downgraded to earlier versions, e.g., B5009D1509. If version downgrade is really required, contact our customer service staff.
- 2. Reversion to P10D1604 or earlier is not allowed once the firmware is upgraded to P12D1611 or later. Contact our technical support if reversion is necessary in an exceptional case.

### 4 Version Upgrade Procedure

- 4.1 Upgrade Overview
- 4.1.1 Version Upgrade Environment
  - 1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

#### 4.1.2 Version Upgrade Modes

You can upgrade through the Web.

### 4.2 Upgrade Procedure

#### 4.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as admin (default password:123456).
- (2) Click **System > Maintenance**. The **Maintenance** page is displayed.

Firmware Upgrade			
Upgrade File		Browse	Upgrade Upgrade Boot Program
Device Restart			
Restart	Restart the device.		
🗌 Enable Auto Restart	Each Day 02:00:00	OK	
Config Management			
Default	Keep current network and user settings and restore other settings to defaults.		
Importing		Browse	Import
Exporting	C:\Users\Desktop\tftp	Browse	Export
Diagnosis Info			
Storage Path	C:\Users\MyLocalFiles\Debug\	Browse	Download

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC\_HCMN2101-XXXXX.zip, and then click **Open**.
- (4) Click Upgrade. You cannot operate on other pages during the upgrade process.

Zhejiang Uniview Te	echnologies Co., Ltd		Release Notes
Maintenance			
Firmware Upgrade			
Upgrade File	C:\Users\Desktop\tftp\IPC G6102-B5005D1509.zip	Browse	Upgrade Upgrade Boot Program
Device Restart			
Restart	Restart the device.		
Enable Auto Restart	Each Day V 02:00:00	OK	
Config Management			
Default	Keep current network and user settings and restore other settings to defaults.		
Importing		Browse	Import
Exporting	C:\Users\Desktop\tftp	Browse	Export
-Diagnosis Info			
Storage Path	C:\Users\MyLocalFiles\Debug\	Browse	Download

(5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.