IPC_Q1201-B5010D1510

Release Notes

Zhejiang Uniview Technologies Co., Ltd

IPC_Q1201-B5010D1510 Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for IPC_Q1201-B5010D1510.

Acronym:

Acronym	Full Name
IPC	IP Camra

Content

1 Version Information3
1.1 Version Number ······3
1.2 Release History ······3
1.3 Version Mapping Table3
2 Feature Change Description
2.1 New features
2.2 Solved issue4
3 Version Upgrade Description
4 Version Upgrade Procedure
4.1 Upgrade Overview ······4
4.1.1 Version Upgrade Environment ······4
4.1.2 Version Upgrade Modes·····4
4.2 Upgrade Procedure ······4
4.2.1 Upgrade Through the Web ······4

1 Version Information

1.1 Version Number

IPC_Q1201-B5010D1510

1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_Q1201-B5010D1510	IPC_Q1201-B5009D1509	2015-11-13	improved release

1.3 Version Mapping Table

Table 2 Version mapping table

Product Mapping Item	Version No. (For External)
NVR-B200-E4@32	B3115P30
NVR304-32E	B3115P30

Table 3 Product models and corresponding versions

Product Series	IPC Series	Initial Version
Series	IPC562E, IPC3231ER, IPC3234SR, IPC2322EBR, IPC2324EBR IPC3232ER	
Models	IPC562E series:IPC562E-DUG	B150601P02
	IPC3231ER series:IPC3231ER-DV	B150801P01
	IPC3234SR series:IPC3234SR-DV, IPC3234SR3-DVZ28	
	IPC2322EBR series:IPC2322EBR-DPZ28	B5010D1510
	IPC2324EBR series:IPC2324EBR-DPZ28	
	IPC3232ER series: IPC3232ER3-DVZ28	
Target file name	IPC_Q1201-B5010D1510.zip	·

2 Feature Change Description

2.1 New features

1.Half-hour time zone settings.

2.Improved automatic white balance image effect.

2.2 Solved issue

1.Live view cannot be started on EZCloud and EZView when RTSP authentication is enabled.

2.ONVIF registration time sync.

3 Version Upgrade Description

Version B5010D1510 supports normal upgrade.B5010D1510 and later versions cannot be downgraded to earlier versions, e.g., B5009D1509. If version downgrade is really required, contact our customer service staff.


4 Version Upgrade Procedure

4.1 Upgrade Overview

4.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

4.1.2 Version Upgrade Modes

You can upgrade through the Web.

4.2 Upgrade Procedure

4.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as admin (default password: 123456).
- (2) Click Setup > Maintenance > Device Maintenance. The Device Maintenance page is displayed.
- (3) Click **Browse** in the **Firmtware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_Q1201-XXXXX.zip, and then click **Open**.

Firmware Upgrade			
Upgrade File		Browse	Upgrade Upgrade Boot Program
Device Restart			
Restart	Restart the device.		
🗌 Enable Auto Restart	Each Day 02:00:00	OK	
Config Management			
Default	Keep current network and user settings and restore other settings to defaults.		
Importing		Browse	Import
Exporting	C:\Users\Desktop\tftp	Browse	Export
Diagnosis Info			
Storage Path	C:\Users\MyLocalFiles\Debug\	Browse	Download

(4) Click Upgrade. You cannot operate on other pages during the upgrade process.

Maintenance			
Firmware Upgrade			
Upgrade File	C:\Users\Desktop\tftp\IPC G6102-B5005D1509.zip	Browse	Upgrade Upgrade Boot Program
Device Restart			
Restart	Restart the device.		
🗌 Enable Auto Restart	Each Day V 02:00:00	ОК	
Config Management			
Default	Keep current network and user settings and restore other settings to defaults.		
Importing		Browse	Import
Exporting	C:\Users\Desktop\tftp	Browse	Export
-Diagnosis Info			
Storage Path	C:\Users\MyLocalFiles\Debug\	Browse	Download

(5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

© 2014-2015, Zhejiang Uniview Technologies Co., Ltd. All Rights Reserved.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Zhejiang Uniview Technologies Co., Ltd.

The information in this manual is subject to change without notice.