

IPC\_Q1201-B5016P01D1604

## Release Notes

Zhejiang Uniview Technologies Co., Ltd

## IPC\_Q1201-B5016P01D1604 Release Notes

**Keywords:** Version information, version upgrade

**Abstract:** This document provides detailed version information and upgrade procedure for IPC\_Q1201-B5016P01D1604.

**Acronym:**

Acronym	Full Name
IPC	IP Camra

# Content

- 1 Version Information..... 3
  - 1.1 Version Number .....3
  - 1.2 Release History .....3
  - 1.3 Version Mapping Table.....3
- 2 Feature Change Description ..... 4
- 3 Version Upgrade Description ..... 4
- 4 Version Upgrade Procedure ..... 4
  - 4.1 Upgrade Overview.....4
    - 4.1.1 Version Upgrade Environment.....4
    - 4.1.2 Version Upgrade Modes.....4
  - 4.2 Upgrade Procedure .....4
    - 4.2.1 Upgrade Through the Web .....4

# 1 Version Information

## 1.1 Version Number

IPC\_Q1201-B5016P01D1604

## 1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_Q1201-B5016P01D1604	IPC_Q1201-B5013P01D1602	2016-6-7	improved release

## 1.3 Version Mapping Table

Table 2 Version mapping table

Product Mapping Item	Version No. (For External)
NVR201-04LP	R2318P01
NVR202-08EP	R2318P01

Table 3 Product models table

Product Series	IPC Series
Series	IPC562E, IPC3231ER, IPC3234SR, IPC2322EBR, IPC2324EBR, IPC3232ER, IPC262ER9, PC252ERA, IPC262EFW, IPC3232ER3
Models	<b>IPC562E series:</b> IPC562E-DUG
	<b>IPC3231ER series:</b> IPC3231ER-DV
	<b>IPC3234SR series:</b> IPC3234SR-DV, IPC3234SR3-DVZ28
	<b>IPC2322EBR series:</b> IPC2322EBR-DPZ28
	<b>IPC2324EBR series:</b> IPC2324EBR-DPZ28, IPC2324EBR-DP
	<b>IPC3232ER series:</b> IPC3232ER3-DVZ28
	<b>IPC262ER9 series:</b> IPC262ER9 –DUZ, IPC262ER9-X10DU
	<b>IPC252ERA series:</b> IPC252ERA-X22DUG
	<b>IPC262EFW series:</b> IPC262EFW-DUZ
	<b>IPC3232ER3 series:</b> IPC3232ER3-DUVZ
<b>IPC3232ER3 series:</b> IPC3232ER3-DUV	
Target file name	IPC_Q1201-B5016P01D1604.zip

## 2 Feature Change Description

- 1.Added highlight compensation.
- 2.Added support for general intelligence.(International version)
- 3.Added new models.
- 4.Solved existing problems.

## 3 Version Upgrade Description

Version B5010D1510 supports normal upgrade.B5010D1510 and later versions cannot be downgraded to earlier versions, e.g., B5009D1509. If version downgrade is really required, contact our customer service staff.


## 4 Version Upgrade Procedure

### 4.1 Upgrade Overview

#### 4.1.1 Version Upgrade Environment

##### 1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

#### 4.1.2 Version Upgrade Modes

You can upgrade through the Web.

### 4.2 Upgrade Procedure

#### 4.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click **Setup > Maintenance > Device Maintenance**. The **Device Maintenance** page is displayed.

**Firmware Upgrade**  
Upgrade File  Browse... Upgrade  Upgrade Boot Program

---

**Device Restart**  
Restart  Restart the device.  
 Enable Auto Restart Each Day  OK

---

**Config Management**  
Default  Keep current network and user settings and restore other settings to defaults.  
Importing  Browse... Import   
Exporting  Browse... Export

---

**Diagnosis Info**  
Storage Path  Browse... Download

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC\_Q1201-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.

**Maintenance**

---

**Firmware Upgrade**  
Upgrade File  Browse... **Upgrade**  Upgrade Boot Program

---

**Device Restart**  
Restart  Restart the device.  
 Enable Auto Restart Each Day  OK

---

**Config Management**  
Default  Keep current network and user settings and restore other settings to defaults.  
Importing  Browse... Import   
Exporting  Browse... Export

---

**Diagnosis Info**  
Storage Path  Browse... Download

- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.