

IPC_6201-F5020D1509

Release Notes

Zhejiang Uniview Technologies Co., Ltd

IPC_6201-F5020D1509

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for IPC_6201-F5020D1509.

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

- 1 Version Information..... 3**
 - 1.1 Version Number3
 - 1.2 Release History3
 - 1.3 Version Mapping Table.....3
 - 1.4 New Functions.....3
- 2 Version Upgrade Procedure 3**
 - 2.1 Upgrade Overview.....3
 - 2.1.1 Version Upgrade Environment.....4
 - 2.2 Upgrade Procedure4
 - 2.2.1 Upgrade Through the Web4

1 Version Information

1.1 Version Number

IPC_6201-F5020D1509

1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_6201-F5020D1509	IPC_6201_IN_Eng- F150601P03	2015-10-29	Improved release

1.3 Version Mapping Table

Table 2 Version mapping table

Product Mapping Item	Version No. (For External)
NVR-B200-E4@32	B3115P30
NVR304-32E	B3115P30

Table 3 Product models and corresponding versions

Product Series	IPC Series	Initial Version
Series	IPC241E, IPC242E, IPC241L, IPC242L	
Models	IPC241E series: IPC241E-DLIR-IN, IPC241E-IR-IN, IPC241E-IR-Z-IN	F6215IN14110 2
	IPC242E series: IPC242E-IR-Z-IN	
	IPC241L series: IPC241L-IR-IN, IPC241L-IN, IPC241L-IR-F60-IN, IPC241L-IR-F120-IN	
	IPC242L series: IPC242L-IR-IN, IPC242L-IN, IPC242L-IR-F60-IN, IPC242L-IR-F120-IN	
Target file name	IPC_6201-F5020D1509.zip	

1.4 New Functions

None


2 Version Upgrade Procedure

2.1 Upgrade Overview

2.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

2.2 Upgrade Procedure

2.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click **Setup > Maintenance > Device Maintenance**. The **Device Maintenance** page is displayed.

Firmware Upgrade	
Upgrade File	<input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Upgrade"/> <input type="checkbox"/> Upgrade Boot Program
Device Restart	
<input type="button" value="Restart"/>	Restart the device.
<input type="checkbox"/> Enable Auto Restart	Each Day <input type="text" value="02:00:00"/> <input type="button" value="OK"/>
Config Management	
<input type="button" value="Default"/>	Keep current network and user settings and restore other settings to defaults.
Importing	<input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Import"/>
Exporting	C:\Users\iq02361\Desktop\lftp文件夹\ <input type="button" value="Browse..."/> <input type="button" value="Export"/>
Diagnosis Info	
Storage Path	C:\Users\iq02361\MyLocalFiles\Debug\ <input type="button" value="Browse..."/> <input type="button" value="Download"/>

Note:1. Software upgrade, system restart, restoration to default and configuration import will cause device restart.
2. Restarting the device will interrupt the connection to the device.

- (3) Click **Browse** in the **Software Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_6201-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

© 2014-2015, Zhejiang Uniview Technologies Co., Ltd. All Rights Reserved.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Zhejiang Uniview Technologies Co., Ltd.

The information in this manual is subject to change without notice.