

IPC_HCMN1102-R5028P09D1603

Release Notes

Zhejiang Uniview Technologies Co., Ltd

IPC_HCMN1102-R5028P09D1603

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for IPC_HCMN1102-R5028P09D1603.

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

- 1 Version Information..... 3**
 - 1.1 Version Number3
 - 1.2 Release History3
 - 1.3 Version Mapping Table.....3
- 2 Feature Change Description 4**
- 3 Version Upgrade Procedure 4**
 - 3.1 Upgrade Overview4
 - 3.1.1 Version Upgrade Environment.....4
 - 3.1.2 Version Upgrade Modes.....4
 - 3.2 Upgrade Procedure4
 - 3.2.1 Upgrade Through the Web4

1 Version Information

1.1 Version Number

IPC_HCMN1102-R5028P09D1603

1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_HCMN1102-R5028P09D1603	IPC_HCMN1102-R5028P07D1603	2016-7-7	Improved release

1.3 Version Mapping Table

Table 2 Version mapping table

Product Mapping Item	Version No. (For External)
NVR301-04-P4	B3202
NVR301-08-P8	B3202

Table 3 Product models table

Product Series	IPC Series
Series	IPC6221ER, IPC6221LR,IPC6222ER,IPC641E, IPC6241SR, IPC6242SL, IPC6242SR, IPC641E, IPC642E
Models	IPC6221ER series: IPC6221ER-X20,IPC6221ER-X20P, IPC6221ER-X30, IPC6221ER-X30P
	IPC6221LR series: IPC6221LR-X20S, IPC6221LR-X20SP
	IPC6222ER series: IPC6222ER-X20, IPC6222ER-X20P, IPC6222ER-X30, IPC6222ER-X30P
	IPC6241SR series: IPC6241SR-X22,IPC6241SR-X30, IPC6241SR-X20
	IPC6242SL series: IPC6242SL-X22,IPC6242SL-X33, IPC6242SL-X22G、IPC6242SL-X33G
	IPC6242SR series: IPC6242SR-X22,IPC6242SR-X30, IPC6242SR-X33、IPC6242SR-X20
	IPC641E series: IPC641E-X22I-IN, IPC641E-X22-IN, IPC641E-X22IR-IN
IPC642E series: IPC642E-X22I-IN, IPC642E-X22-IN, IPC642E-X22IR-IN	
Target file name	IPC_HCMN1102-R5028P09D1603.zip

2 Feature Change Description

Table 4 Feature Change Description

Item	Feature	Description
Newly added features	detection mode	motion detection area configuration by grid.


3 Version Upgrade Procedure

3.1 Upgrade Overview

3.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

3.1.2 Version Upgrade Modes

You can upgrade through the Web.

3.2 Upgrade Procedure

3.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password:123456).
- (2) Click **Setup > Maintenance > Device Maintenance**. The **Device Maintenance** page is displayed.

Firmware Upgrade

Upgrade File Upgrade Boot Program

Device Restart

Restart the device.

Enable Auto Restart

Config Management

Keep current network and user settings and restore other settings to defaults.

Importing

Exporting

Diagnosis Info

Storage Path

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_HCMN1102 -XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.

Maintenance

Firmware Upgrade

Upgrade File Upgrade Boot Program

Device Restart

Restart the device.

Enable Auto Restart

Config Management

Keep current network and user settings and restore other settings to defaults.

Importing

Exporting

Diagnosis Info

Storage Path

- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.