

IPC_HCMN1102_IN_Eng-F150401

Release Notes

Zhejiang Uniview Technologies Co., Ltd

IPC_HCMN1102_IN_Eng-F150401

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for IPC_HCMN1102_IN_Eng-F150401.

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

1 Version Information	3
1.1 Version Number	3
1.2 Release History	3
1.3 Version Mapping Table	3
1.4 New Function	3
1.4.1 mproved Features:	3
1.4.2 Issues:	3
2 Version Upgrade Procedure	4
2.1 Upgrade Overview	4
2.1.1 Version Upgrade Environment.....	4
2.1.2 Version Upgrade Modes.....	4
2.2 Upgrade Procedure	4
2.2.1 Upgrade Through the Web	4

1 Version Information

1.1 Version Number

IPC_HCMN1102_IN_Eng-F150401

1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_HCMN1102_IN_Eng-F150401	IPC_HCMN1102_IN_Eng-F141201P05	2015-07-06	Release of improvement

1.3 Version Mapping Table

Table 2 Version mapping table

Product Mapping Item	Version No. (For External)
NVR202-08E	B2310P10
NVR208-16	B2210P10

Table 3 Product models and corresponding versions

Product Series	IPC Series	Initial Version
Series	IPC141E, IPC142E、IPC64X、IPC622X	
Models	IPC141E series: IPC141E-X22-IN, IPC141E-X22-NL-IN	F141201
	IPC142E series: IPC142E-X22-IN, IPC142E-X22-NL-IN	
	IPC64X series: IPC641E、IPC641L、IPC641ER、IPC641EI、IPC642E、IPC642L、IPC642ER	
Target file name	IPC_HCMN1102_IN_Eng-F150401.zip	

1.4 New Function

1.4.1 Improved Features:

- (1) QR code available on the Web interface of IP camera.
- (2) Supports ONVIF snapshot.
- (3) Improved security features.
- (4) Supports cloud upgrade of IP cameras through the NVR.
- (5) Supports Korean PTZ protocol.
- (6) Supports multiple streams.

1.4.2 Issues:

- (1) Improved ONVIF support.
- (2) Improved the response speed when setting privacy mask.
- (3) Same OSD size on the same display at different resolutions.


2 Version Upgrade Procedure

2.1 Upgrade Overview

2.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

2.1.2 Version Upgrade Modes

You can upgrade through the Web.

2.2 Upgrade Procedure

2.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: admin).
- (2) Click **Setup > Maintenance > Device Maintenance**. The **Device Maintenance** page is displayed.

<ul style="list-style-type: none"> Basic Service Intelligence Settings Events <li style="background-color: #0070C0; color: white;">Maintenance Device Status User Management Device Maintenance 	<p>Current Location: Maintenance >> Device Maintenance</p> <hr/> <p>Software Upgrade</p> <p>Upgrade File <input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Upgrade"/></p> <hr/> <p>System Restart</p> <p style="text-align: right;"><input type="button" value="Restart"/></p> <hr/> <p>Config Management</p> <p style="text-align: right;"><input type="button" value="Default"/></p> <p>Importing <input type="text"/> <input type="button" value="Browse..."/> <input type="button" value="Import"/></p> <p>Exporting <input type="text" value="C:\MyLocalFiles\Debug\"/> <input type="button" value="Browse..."/> <input type="button" value="Export"/></p> <hr/> <p>Diagnosis Info</p> <p>Storage Path <input type="text" value="C:\MyLocalFiles\Debug\"/> <input type="button" value="Browse..."/> <input type="button" value="Download"/></p> <hr/> <p>Focus</p> <p>Min. Focus Distance(cm) <input type="text" value="100"/> <input type="button" value="OK"/></p> <hr/> <p>Note: 1. Software upgrade, system restart, restoration to default, configuration import and changing minimum focus distance will cause device restart. 2. Device restart will interrupt connection with the device.</p>
---	---

- (3) Click **Browse** in the **Software Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_HCMN1102_IN_Eng-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

© 2014-2015, Zhejiang Uniview Technologies Co., Ltd. All Rights Reserved.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of Zhejiang Uniview Technologies Co., Ltd.

The information in this manual is subject to change without notice.